


Instruction Manual



RL-6155

SIZE: 1570X1570X660

Preparations

Dear Customers:



Thank you for purchasing our products. Prior to the installation and initial use of the bathtub, please read carefully the instructions that can be helpful when using this product.

We will not be liable for improper use of our products.



Our products are subject to constant development of our product, because there may be changes in design and use other components. If you have any questions, please contact us or distributors. We will help you much






WARNING

1. People who suffer from heart disease, hypertension and diabetes should not use a steam shower or hot bath. (It is suggested that children should be accompanied by an adult to take a bath)
2. Take a bath, not only after you drink alcohol or have taken excessive Sports.
3. The bathing water should be below 45 ° C during the recommended temperature is 30 ° C -38°
4. Don't take a bath for a long time. Recommended time: Suggested time: 15-21 minutes
5. We reserve the right to change information at any time.
6. Also settings, configurations and details of products are subject to change.
7. For maintenance, you should contact the engineers, appointed by the dealer. Fix yourself and do not break down, otherwise the supplier is not liable for damages that may occur.



No.	Description	Qte	No.	Description	Qte
01	Start switch	1pc	09	air jet	16pcs
02	pillow	2pcs	10	big water jets	4pcs
03	Divert knob	1pc	11	underwater light	3pcs
04	cold water volume	1pc	12	computer panel	1pc
05	hot water volume	1pc	13	drain switch	1pc
06	waterfall faucet	2pcs	14	Floor drain	1pc
07	handshower	1pc	15	water circulation	1pc
08	small water jets	8pcs	16	air jet	8pcs





IMPORTANT NOTES:

1. The installation must be performed by a technician qualifizeirten
2. The electronic parts should be well grounded, otherwise the manufacturer is not responsible for disruptions and damage.
3. The installer is responsible for ensuring that the hot tub with plenty of FI-hedging is installed correctly.
4. For the functions that could not be activated after the above instructions, please contact the authorized technician or the local dealer.
5. If you do not use the product for a long time, please disconnect the main power and turn off the water.
6. The hot tub is absolutely connect with an aqua-stop, this prevents leakage in case of rupture of a pressure hose, water.
7. It should be used only drinking water for bathing. Rain water or well water, destroy valves and piping are not good.

Cleaning & Maintenance

1. During transit can loosen screws. Tighten all screws and check all connections before the pool building.
2. Removal with a soft cloth with mild detergent possible contamination from the surface, the metal parts (valves, etc), you can polish with a cloth.
3. The lime can be wiped clean with warm citric acid or vinegar with a soft cloth. Do not use acetone and / or ammonia-based cleaners.
4. Do not clean the tub and accessories with a hard or coarse material to prevent scratches.
5. Clean the tub and accessories come with gasoline to prevent damage.
6. It is not recommended to have water for a long time in the bath tub or use it for laundry washing. Allow the water to the bath off and disconnect the power supply.

7. Power should be strong enough and be grounded
8. To ensure your safety must be a professional engineer that the grounding line is well grounded and an RCCB fitted during installation.

Important:

Bathing should not go untreated into the environment!

Waste water (sewage) must to be connected to public sewer or an approved sewage treatment plant.